

WBETA002 installation instructions.



Step 1.

Carefully remove screw from front of indicator housing.



Step 2.

Remove lens taking care not to damage locating arm on lens (this plastic is easily stressed if forced).



Step 3.

Remove bulb assembly and reflector as one (a small flat-end screwdriver may help ease this out).



Step 4.

Remove terminal wires from back of bulb assembly. (Needle nose pliers may help).



Step 5.

Fit Indicator locking key (supplied) into locating slot on the arm of the indicator, matching the same position as the arm on the old bulb/reflector assembly.



Step 6.

Re-attach male/female terminal connectors to rear of LED assembly (a long nose pliers again may help big fingers). Note: if indicator does not flash you may have terminals reversed. Check before re-assembly of lens.



Step 7.

Line up the LED assembly with the locking key and carefully push back into housing. Make sure wiring is not trapped.



Step 8.

Replace lens and screw into housing, taking care not to stress the arm on the lens. Do not force.



Step 9.

Enjoy!